

## Asbestos Chain of Custody

Customer Information	Tests Requested **																			
Contact name: _____ Email: _____ Company name: _____ Address: _____ City: _____ Prov.: _____ Postal Code: _____ Telephone: _____ PO#: _____ Econotech contact: _____ Project location: _____	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="text-align: left;"><i><b>Turnaround time required</b></i></th> <th colspan="3" style="text-align: center;"><b>business days</b></th> </tr> <tr> <th style="text-align: center;">Asbestos (in-house)</th> <th style="text-align: center;">ICP Lead (Pb)</th> <th style="text-align: center;">Sublets</th> </tr> </thead> <tbody> <tr> <td>Extended:</td> <td style="text-align: center;">2 to 3</td> <td style="text-align: center;">NA</td> <td style="text-align: center;">7 to 10</td> </tr> <tr> <td>Regular:</td> <td style="text-align: center;">1</td> <td style="text-align: center;">7 to 10</td> <td style="text-align: center;">4 to 6</td> </tr> <tr> <td>RUSH:</td> <td style="text-align: center;">4 hrs</td> <td style="text-align: center;">4 to 6</td> <td style="text-align: center;">2 to 3</td> </tr> </tbody> </table> Special Instructions: _____	<i><b>Turnaround time required</b></i>	<b>business days</b>			Asbestos (in-house)	ICP Lead (Pb)	Sublets	Extended:	2 to 3	NA	7 to 10	Regular:	1	7 to 10	4 to 6	RUSH:	4 hrs	4 to 6	2 to 3
<i><b>Turnaround time required</b></i>	<b>business days</b>																			
	Asbestos (in-house)	ICP Lead (Pb)	Sublets																	
Extended:	2 to 3	NA	7 to 10																	
Regular:	1	7 to 10	4 to 6																	
RUSH:	4 hrs	4 to 6	2 to 3																	

Sample Information						Air samples only			Indicate preferred testing method						
Sample # <small>(Lab use only)</small>	Customer's Sample Identification/Location	# of samples	Date sampled	Positive stop	HA* (Y/N)	Type	Flow rate	Time (mins)	PLM (bulk)	PCM (air)	Lead (Pb)	TEM	EPA 04-400	400 point count	1000 point count

\* HA = Homogenous Area  
 \*\* Please refer to next page for information on tests offered and rush requests

Released by: \_\_\_\_\_  
 Date/Time: \_\_\_\_\_

Received by: \_\_\_\_\_  
 Date/Time: \_\_\_\_\_

## Asbestos Testing Information

Test Type	Sample Type	Detection Limit	Turnaround Time	Price per sample, CA\$
			Rush   Normal   Extended	
PLM (NIOSH 9002)	Bulk samples	<1% (visual estimate)	4 hrs   1   2-3	90   60   45
PCM (NIOSH 7400)	Air Cassettes	<0.01 fibres/mL	4 hrs   1   2-3	90   60   45
Lead (ASTM E-1645 ICP)	Paint	sample size dependent	4-6   7-10   NA	124   83   NA
TCLP Lead <sup>†</sup> (EPA 1311/6010C)	Bulk samples	sample size dependent	2-3   4-6   7-10	Call for pricing
TEM <sup>†</sup>	Bulk and/or Air	<0.01%	2-3   4-6   7-10	Call for pricing
EPA600-116-04-400 <sup>†</sup>	Vermiculite Only	sample size dependent	2-3   4-6   7-10	Call for pricing
400 Point Count <sup>†</sup>	Bulk samples	<0.25%	2-3   4-6   7-10	Call for pricing
1000 Point Count <sup>†</sup>	Bulk samples	<0.10%	2-3   4-6   7-10	Call for pricing

† = tests sublet to partner labs.

NA = not available

Times represent regular business days

RUSH requests add a 50% surcharge to the *normal* turnaround time prices.

Samples will be processed and analyzed immediately.

Rush turnaround times...

Asbestos: Within 4 hours from receipt of samples.

Lead (Pb): 3 to 5 days from receipt of samples.

(Turnaround times may vary for high sample volumes, difficult matrices or condition of samples.)

### Acronyms

PCM = Phase Contrast Microscopy

PLM = Polarized Light Microscopy

TEM = Transmission Electron Microscopy

NIOSH = National Institute for Occupational Safety and Health (US)

ASTM = American Society for Testing and Materials (Int'l)

EPA = Environmental Protection Agency (US)

CCOHS = Canadian Centre for Occupational Health and Safety (CA)

### Useful links

General asbestos information (<https://www.ccohs.ca/oshanswers/chemicals/asbestos/whatis.html>)

Asbestos in homes (<https://www.ccohs.ca/oshanswers/chemicals/asbestos/home.html>)